

INCLINABLE LYRE EASEL

model AA13405

assembly instructions

STEP 1

C (x2)

STEP 2

(This piece spins freely. Facing is not important until Step 6.)

B (x2)

STEP 3

STEP 4

D (x6)

STEP 5

E (x3)

F

STEP 6

A

STEP 7

Do not tighten fully. Loosen screws if center mast will not adjust smoothly.

G (x2)

STEP 8

A